


NOTE:


DO NOT CUT THE PLASTIC WRAP AROUND THE BACK FRAME UNTIL ASSEMBLY IS COMPLETE.

Step 1:

Set one side frame on the ground with the pockets facing up. Place the head and seat frame into the pockets. Set the back frame onto the side frame.

**Step 2:**

Place the other side frame on top and insert the head and seat frame into the pockets. Also, line up the back frame with the holes of the side frame. Attach using A- screws. Flip and repeat on the other side.

**Materials:**

- (1) Hardware Pack
- (1) Head piece
- (1) Back frame
- (1) Seat frame
- (2) Side frame
- (2) Leg brace
- (2) Rocker bottom

TOOLS REQUIRED:

Allen Wrench Included

Phillips Screw-Driver
Not Included

Note: Do not use an impact driver to install hardware. Use battery operated drill or provided Allen wrench.


- (14) A - $\frac{3}{8}$ "-20 x 2- $\frac{1}{2}$ " Hex Screw




- (4) B - 2" Phillips screw

**Step 3:**

Attach the two braces using B- Screws.

**Step 4:**

Set the rocker on its side. Attach rocker bottoms with A- screws.



Item Number: 51137/51151/51135

注意：

請勿在組裝還未完成之前，便將椅背框架周圍的塑膠包裝材料切除。

材料：

- (1) 五金零件包
- (1) 椅背頂端部分
- (1) 椅背框架
- (1) 座部框架
- (2) 椅側框架
- (2) 椅腳支撐架
- (2) 搖桿底部

需使用的工具：

已附內六角扳手

十字型螺絲起子
未附

注意：請勿使用衝擊起子安裝五金零件。
使用電池啟動的電鑽或是內附的內六角扳手。

(14) A - 14-20 x 2-12英寸六角螺絲




(4) B - 2英寸十字螺絲




步驟1：

將一個椅側框架，將安裝孔朝上擺放在地面。
椅背頂端及座部框架放入安裝孔。
將椅背框架裝設於椅側框架內。




步驟2：

椅側框架的另一側放在上端，並將椅背頂端和座部框架裝入安裝孔。
同樣的，將椅側框架的安裝孔與椅背框架對齊。
使用A - 螺絲安裝固定，將組件翻轉過來重複另一側的安裝作業。




步驟3：

使用B - 螺絲將兩根支撐架安裝固定。



步驟4：

將搖桿安裝在兩側。
使用A - 螺絲安裝固定搖桿底部。



品項編號：S1137/S1151/S1135