



Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku, Kaneda-Nishi
361 Urakura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco Wholesale New Zealand Limited
2 Gunton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca
* faisant affaire au Québec sous
le nom les Entrepôts Costco

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco Wholesale Spain S.L.U.
Polígono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr


Costco (China) Investment Co., Ltd.
No. 5178, KangXin Road,
Pudong New Area, Shanghai
China 201315
+86-21-6257-7065

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se

Cascade Mountain Technologies LLC
www.cascademountaintech.com

零件與客戶服務:
customer@casademountaintech.com

可調高度躺椅




ITM. / ART. 1654561
HMK2-24-C
組裝說明


重要說明書：請妥善保存以供日後參考。

組裝支架


商品內容：



提袋



支架




椅布

設置步驟：

將椅腳和支架插入連接器。將椅腳(含黑色沙灘椅腳座)放在平坦、穩固的地面上。確保鋁管完全插入連接器中，並進行下一步。


注意：請確保以相同方式安裝每一支椅腳。詳細資訊請參考「調整高度」。

將橫桿(帶黃色蓋子)插入相應的連接點(黃色箭頭所指之處)，連接前側橫桿



安裝椅布


將鋁管末端插入角落的口袋內，安裝椅布。



調整高度

欲調整椅子高度，請將椅腳從朝下的插槽中取出，並移動到朝上的插槽中。

注意：使用前請確保椅腳完全插入相應的插槽中。



使用與維護

供戶外、露營使用。不可於室內使用。使用海綿、中性肥皂與清水清洗。請勿使用研磨性清潔劑或菜瓜布，以免損壞椅子的材質或支架。不使用時，請拆卸椅子並收納於隨附的攜行袋中。收納前請確保座椅已完全乾燥。請收納於有遮蓋之處或室內。

注意

僅供成人使用。使用者請務必平穩坐在椅子上，請勿單獨施加重量於座椅的前、後或側邊。坐椅子時請勿將椅子向後仰。使用椅子時，四支椅腳應保持接觸地面。小心明火。此座椅應在平坦、穩固的地面上使用。未正確組裝座椅或在不穩定的地面上使用可能導致座椅傾倒及人員受傷。座椅支架未正確使用可能會彎曲變形。